



Read this important document in its entirety before using installing and using the products

VERY IMPORTANT: Do not connect OkyWeb2 to computer before installing software

This is a USB device and must be installed according to procedure. Failure to follow these procedures will cause serious communication issues between the software and the player. The warranty does not cover returns based on issues where the user has ignored this advice.

Step 1: Install software before connecting OkyWeb 2 to computer

1. Install the latest OkyWeb2 Operating software from the CD. Open the folder 'OkySoft 2 Software' and run SETUP.EXE. Install the program and accept all default values.
2. Reboot the PC
3. Connect OkyWeb2 to the computer via the included USB cable and power up.
(Note) turn OkyWeb2 on and off by holding the STOP button for a few seconds

Step 2: Installing the USB drivers

Having installed the software, rebooted and with OkyWeb2 connected to a USB port, the hardware wizard should detect and install the USB drivers for this device. Allow Windows to automatically find and install the drivers.

During installation of the USB drivers, alert boxes may appear on screen warning you about 'unsigned drivers' or 'viruses'. If any warnings about installing unsigned drivers or viruses etc, appear on the screen, it is perfectly safe to ignore them. Press '**CONTINUE**' to complete the installation process. Do not interrupt the installation of this critical step – press YES or OK wherever prompted. Always connect OkyWeb2, to the same USB port.

Updating Firmware

This model contains the latest firmware **1.26** and does not require updating. You will receive an email if a new firmware version is released.

User Manual

User Manual and Software Manual are available from www.okyweb.com.au. We suggest reading the user manuals before installing and using your OkyWeb2 Player.

Power Supply: USA customers - the wall plug is either Australian/Euro socket. Take the wall plug to your local Wal-Mart or good electronics store and request a replacement power pack to suit USA wall connection. Replacement will cost only a few dollars and this has been factored into price. Please ensure the specifications are correct to avoid cancelling the warranty.

OkyWeb Technical Support

Call: (03) 9887 8127 within Australia or +613 9887 8127 if you reside outside Australia for personal support or email: info@okyweb.com.au